
INSTALLATION & USER MANUAL

Mechanical Installation

The Art'ceinte flat speakers are designed to be used in a dry environment. Ensure your wall will support the Art'ceinte flat speakers. The weight per speaker is 7kg for the Art'ceinte500 model and 10kg for the Art'ceinte800 model. Fixation material is not supplied by BEISEM.

The speakers are equipped with 2 fixation points to hang the speaker at level on the wall. Due to the fact that the speakers are not symmetric mounted in there housing, the flat speaker is not in balance; we advice to use 2 fixation points on your wall or ceiling and both fixation points of the flat speaker to assure a straight level.



Specifications

system 2 way closed case

 $\begin{array}{ll} impedance & 8\Omega \\ nominal \ power & 50W \\ maximal \ power & 80W \end{array}$

frequency range 90 - 20.000Hz

frequency cut-off 3000Hz


Speaker connection

- 1. check if your amplifier is suitable to use in combination with the Art'ceinte flat speakers. Speaker specifications: 50W (RMS) at 8 Ohm
- 2. before connecting the speaker, assure yourself the power supply of your amplifier and/or other audio material has been turned off.
- 3. the speakers need to be connected with 2-wired speaker cable with a minimum diameter of 0,75mm²

4. you'll find the connectors on the backside of your speakers.

5. Connect the cables to the speakers and assure yourself of the right polarity of the speakers. red connector for + (plus), black connector for - (minus)





Maintenance

The Art'ceinte flat speakers don't need any special maintenance. Clean your speakers with a soft dry cloth to remove dust.

Threat your speakers as a painting:

- Don't touch the surface with a moist or wet cloth.
- Don't touch the surface with any cleaning product.
- BEISEM doesn't accept any claims caused by mistreatment of the surface.

Guarantee

All our products have been fabricated according to the highest quality standards and have been tested. However it's possible during production, testing or transport something went wrong.

- 1. you have one (1) year standard guarantee on your flat speakers
- 2. the starting date for the guarantee is the date mentioned on your invoice.
- 3. the guarantee void if you open the speakers yourself or by any other person then indicated by BEISEM.
- 4. Wrongly installed or wired speakers won't be covered by our guarantee.
- 5. Damage caused on your audio system won't be covered by our guarantee.
- 6. Transportation costs are not covered by our guarantee.

